

MIRRORS

BUS BOY MIRRORS

AMTRAM	
52-520	One Pair
52-520BA	Base Assembly

BLUE BIRD	
52-518	One Pair
52-518BA	Base Assembly

BLUE BIRD MINI	
52-514	One Pair
52-514BA	Base Assembly

CARPENTER CAD.	
52-514	One Pair
52-514BA	Base Assembly

CARPENTER WAYNE PUSHER	
52-522	One Pair
52-522BA	Base Assembly

CHEVROLET	
52-504	One Pair
52-504BA	Base Assembly

FORD	
52-505	One Pair
52-505RBA	Base Assembly
52-505LBA	Base Assembly
52-535	Pre 1992 Van
52-535BA	Base Assembly
52-537	One Pair 1995
52-537BA	Base Assembly
52-545	1992 Van & Newer
52-545BA	Base Assembly

NAVISTAR	
52-5001	One Pair
52-5001BA	Base Assembly
52-5001LBA	Base Assembly

INTERNATIONAL	
52-501	One Pair
52-501BA	Base Assembly

THOMAS	
52-5012	1993 Thomas Vista
52-5012RBA	Base Assembly
52-5012LBA	Base Assembly

THOMAS PUSHER	
52-518	One Pair
52-518BA	Base Assembly



- 741611** Mirror Head Back Cap
- 74-60** Yellow Plugs (Bag of 6)
- 74-75** 3/4" Center Line Clamp
- 74-80** 5/8" Clamp
- 52-100** Bus Boy Gasket
- 52-200** Bus Boy Gasket & Lens
- 52-300** Bus Boy Gasket & Lens Heated
- 52-500** Bus Boy Head Unheated
- 52-600** Bus Boy Head Heated
- 741032** Well Nuts (Bag of 6)

CROSS OVER MIRRORS

MIRROR ASSEMBLIES	
50-805	Adjustable Tripod Mirror Assebmly
50-896	IHC Swing Away Base Pre 1990
50-897	Ford Swing Away Base & Arm RH Pre 1996
50-898	Ford Swing Away Base & Arm LH Pre 1995
50-910	GM Swing Away Base & Arm

REPLACEMENT PARTS & ACCESSORIES	
54-85	8" Convex • Center Mount • Black Mirror Head
54-86	8" Convex • Off Center Mount • Black Mirror Head
54-89	"Dolly" Elliptical • Off Center Mount • Black Mirror Head
50-5	Bracket To Mount Additinal 8" Convex Mirror Head
74-58	5/8" Center Line Clamp
74-90	Mouting Foot
74-101	Adjustable Arm Black

