

National 1.800.433.5613 • Within Texas 1-800-792-1011

# WHEELCHAIR RESTRAINTS

# Kit No. AL712S-4C

Auto-tensioning, auto-locking retractor kit complete with S-Hooks and occupant restraint system. Kit includes:



AL7008555 (2) Auto-tensioning retractor assembly with stud fitting and S-Hook, RH.

AL7009075 (2) Auto-tensioning retractor assembly with stud fitting and S-Hook, LH.

**AL700771 (1)** Fixed-point mount occupant restraint retractor with height adjuster and triangular fitting.

AL700771-1 (1) Occupant restraint buckle connector assembly with triangular fitting.

# Kit No. AL712-4C

Auto-tensioning, auto-locking retractor kit complete with buckle, buckle connector and occupant restraint system. Kit includes: \_\_\_\_\_



AL700855 (2) Auto-tensioning retractor assembly with stud fitting and buckle & buckle connector, RH.

AL700907 (2) Auto-tensioning retractor assembly with stud fitting and buckle & buckle connector, LH.

**AL700771 (1)** Fixed-point mount occupant restraint retractor with height adjuster and triangular fitting.

AL700771-1 (1) Occupant restraint buckle connector assembly with triangular fitting.

### Kit No. AL727S-4C

Auto-tensioning, auto-locking retractor kit complete with S-Hooks. Kit includes:



**AL7008555 (2)** Auto-tensioning retractor assembly with stud fitting and S-Hook, RH.

**AL7009075 (2)** Auto-tensioning retractor assembly with stud fitting and S-Hook, LH.

### Kit No. AL727-4C

Auto-tensioning, auto-locking retractor kit complete with buckle and buckle connector. Kit includes:



#### AL700855 (2) Auto-tensioning retractor assembly with stud

fitting and buckle & buckle connector, RH.

AL700907 (2) Auto-tensioning retractor assembly with stud fitting and buckle & buckle connector, LH.