MIRROR-LITE PRODUCTS



Mirror Lite's Safety Cross Mirror Systems

Freightliner

PART#	DESCRIPTION:	UNIT:
170-070A	1" Freightliner, Non-Heated, Black	Pair
170-080A	1" Freightliner, Heated, Black	Pair
170-090A	1" Freightliner, Non-Heated, Stainless Steel	Pair
170-200A	1" Freightliner, Heated, Stainless Steel	Pair
170-070AR	1" Freightliner, Non-Heated, Black Right Side Only with Mirrors	Each
170-070AL	1" Freightliner, Non-Heated, Black Left Side Only with Mirrors	Each
170-080AR	1" Freightliner, Heated, Black Right Side Only with Mirrors	Each
170-080AL	1" Freightliner, Heated, Black Left Side Only with Mirrors	Each
170-090AR	1" Freightliner, Non-Heated, Stainless Steel, RH side w/ Mirror	Each
170-090AL	1" Freightliner, Non-Heated, Stainless Steel, LH side w/ Mirror	Each
170-200AR	1" Freightliner, Heated, Stainless Steel, RH side w/ Mirror	Each
170-200AL	1" Freightliner, Heated, Stainless Steel, LH side w/ Mirror	Each



Base & Arm Assemblies

PART#	DESCRIPTION:	UNIT:
170-070RBA	1" Freightliner, Black, RH Base & Arm only	Each
170-070LBA	1" Freightliner, Black, LH Base & Arm only	Each
170-090RBA	1" Freightliner Stainless Steel, RH Base & Arm only	Each
170-090LBA	1" Freightliner Stainless Steel, LH Base & Arm only	Each

Mani Arm only and Brace Arms

PART#	DESCRIPTION:	UNIT:
74-8938	1" Freightliner, Black, Main Arm, Fits RH & LH sides	Each
74-8938SS	1" Freightliner, Stainless Steel, Main Arm, Fits RH & LH sides	Each
74-8939	18" Freightliner Black Brace Arm (5/8" Tubing)	Each
74-8939SS	18" Freightliner, Stainless Steel Brace Arm (5/8" Tubing)	Each
74-8940	11.5" Freightliner Black Brace Arm (5/8" Tubing)	Each
74-8940SS	11.5" Freightliner Stainless Steel Brace Arm (5/8" Tubing)	Each

Mirror Head Replacement Parts	
DESCRIPTION"	

Non-Heated Mirror Head

PART#

SC070A

SC080A	Heated Mirror Head	Each
10-600	Heater Pad w/ Wire	Each
PART#	DESCRIPTION:	Cost:
74-34100	1" Stainless Steel Loop	
74-57	5/16-18X3/4" Stainless Steel Bolt	
74-191	5/16-18 Stainless Steel Flange Nut	
74-BELL	Bell Mount Includes: Bolt, L-foot, Back-up Plates, Gaskets	
74-1032	Well Nuts	
74-596R-1	Black RH Cast Freightliner Base w/Cap and Screws	
74-596L-1	Black LH Cast Freightliner Base w/Cap and Screws	





Cast Base Right & Left

UNITS: