

WHEELCHAIR RESTRAINTS OCCUPANT RESTRAINT SYSTEMS

Premium Lap Belts

Each Premium Lap Belt contains three push-button buckles for greater versatility of attachment, two web adjusters for increased placement capability and web stiffeners for ease of installation.

FE200600

For Series L Track 108" Long

FE200600

For Series A Track 108" Long

No Pictures Available

Parallel Lap Belts

Standard Lap Belts

Each Standard Lap Belt contains a single push-button buckle and two web adjusters for increased placement capability.

FE200594



For Series L Track 98" Long

FE200601



For Series A Track 98" Long

Integrated Lap Belts

Each Integrated Lap Belt contains a single push-button buckle, webbing adjuster(s) and web stiffeners for ease of installation. For use with the FF600 and FE500 Series Securement Systems only.

FE200842



FF600 Series Systems With two
webbing adjusters

FE200595



FF500 Series Systems With one
webbing adjuster

Integrated Lap Belts

Lap Belt Extensions

The Lap Belt Extension contains a single push-button buckle.

FE200842

12" long

FE200842

20" long



WHEELCHAIR RESTRAINTS OCCUPANT RESTRAINT SYSTEMS



Integrated Combination Belts

The FE200727 Integrated Combination Belt provides a shoulder belt and integrated lap belt that are incorporated into a fully retractable unit. It combines the automatic adjustability of a retractable shoulder belt with the easy installation of an integrated lap belt. Since the integrated Combination Belt retracts to the vehicle sidewall, there is no need to provide separate storage for the occupant restraint belts. A Velcro® strap is provided to keep the belt ends up against the vehicle sidewall when not in use. The FE200727 is for use with the FE500 and FF600 Series Wheelchair Securement Systems only.

The retractor mechanism can be mounted directly to the vehicle floor or sidewall, or into Series L Aluminum Track with the use of two FE200747 Series L Mounting Kits. The belt web guide can be installed to the vehicle sidewall by using the FE200745 Sidewall Mounting Kit, or into Series L Aluminum Track with the FE200747 Series L Mounting Kit.

FE200727

NOTE: When mounting integrated combination belts into L Track, use of FE200747 Series L Mounting Kit is required



FE200856

The FE200856 Integrated Combination Belt provides the same great features and benefits as our FE200727. The belt is designed to allow the retractor to be installed on a sidewall rail, which is typically mounted 10 inches above the vehicle floor

Integrated Combination Belt with Patented Height Adjuster

The FE200727 Integrated Combination Belt with Patented Height Adjuster provides a shoulder belt and integrated lap belt, which are incorporated into a fully retractable unit. The simple, easy-to-use Height Adjuster provides nearly 12 inches of vertical adjustment and allows for the proper geometry and placement of the shoulder belt, regardless of passenger size or wheelchair design.

FE200727HA

NOTE: When mounting integrated combination belts into L Track, use of FE200747 Series L Mounting Kit is required



FE200856HA

The FE200856HA Integrated Combination Belt provides the same great features and benefits as our FE200727HA. The belt is designed to allow the retractor to be installed on a sidewall rail, which is typically mounted 10 inches above the vehicle floor

Dual Retractable Integrated Combination Belt

The FE200868-2 Integrated Combination Belt provides unsurpassed flexibility and ease of use. The height of the belt can be adjusted for a perfect fit on the occupant simply by pushing a release button of the upper retractor. In addition to this feature, this belt can be moved front to back along the vehicle sidewall, without the use of tools, by simply removing the quick release L Fittings from the vehicle L Tracks. Note: Series L Track must be installed running front-to-back on the vehicle floor and on the upper section of the vehicle sidewall.

FE200868-2



WHEELCHAIR RESTRAINTS

OCCUPANT RESTRAINT SYSTEMS

Non-Retractable Belts

The Non-Retractable Shoulder Belts are easily attached to a section of track mounted on the vehicle sidewall. This provides increased positioning flexibility for multiple station vehicles,. Note: Recommended for passengers with limited upper body control.

FE200599

For Series L Track 52" Long

FE200732

For Series L Track 82" Long

FE200613

For Series A Track 52" Long

FE200716

For Series A Track 82" Long



Non-Retractable Belt with Patented Height Adjuster

The FE200599HA Series L Non-Retractable Shoulder Belt is easily attached to a section of Series L Track mounted on the vehicle sidewall. This provides increased positioning flexibility for multiple station vehicles. The simple, easy-to-use Patented Height Adjuster provides nearly 12 inches of vertical adjustment and allows for the proper geometry and placement of the shoulder belt, regardless of passenger size or wheelchair design. A Velco® strap is provided to keep the belt ends up against the vehicle sidewall when not in use.

FE200599HA



Non-Retractable Fixed-Point

The FE200710 Fixed-Point Shoulder Belt can be mounted to the existing original equipment shoulder belt location, or with the FE200745 Sidewall Mounting Kit. This is an excellent choice for single, fixed or dedicated position vehicles.

FE200710

52" Long

FE200710L

82" Long



Non-Retractable Fixed-Point with Patented Height Adjuster

The FE200710HA Fixed-Point Shoulder Belt can be mounted to the existing original equipment shoulder belt location or with the FE200745 Sidewall Mounting Kit. This is an excellent choice for single, fixed or dedicated position vehicles. The simple, easy-to-use Patented Height Adjuster provides nearly 12 inches of vertical adjustment and allows for the proper geometry and placement of the shoulder belt, regardless of passenger size or wheelchair design.

FE200710HA



WHEELCHAIR RESTRAINTS

OCCUPANT RESTRAINT SYSTEMS



Non-Retractable Belts

Non-Retractable Fixed-Point Quick Disconnect

The FE200865 Quick Disconnect Shoulder Belt can be mounted to the existing original equipment shoulder belt anchor bolt along with the original equipment shoulder belt.

The Quick Disconnect Shoulder Belt can be easily removed, by tusing the single push-button buckle, to allow a passenger, sitting on the flip seat, to use the original equipment shoulder belt. This belt can then be stored separately.

When a wheelchare is placed in the same area, the Quick Disconnect Shoulder Belt connects to its short anchor strap by using the single push-button buckle. The Quick Disconnect Shoulder Belt then provides the upper body ptotection for the passenger with special needs.

FE200865



Retractable Fixed-Point

The FE200604 Retractable Fixed-Point Shoulder Belt offers automatic adjustment and is ideal for vehicls with single, fixed or dedicated passenger positions. A Velcro® strap is included with FE200604HA to keep the belt ends up against the vehicle sidewall when not in use.

The retractor mechanism can be mounted directly to the vehicle floor or sidewall, or into Series L Aluminum Track with the use of two FE200747 Series L Mounting Kits. The belt web guide can be installed to the vehicle sidewall by using the FE200745 Sidewall Mounting Kit, or into Series L Aluminum Track with the FE200747 Series L Mounting Kit. Note: For passengers with limited upper body control, a non-retractable shoulder belt is recommended.

FE200604

112" Long

FE200604L

136" Long

FE200604HA

136" Long



The FE200936 Fixed-Point Retractable Shoulder Belt features a web sensitive retractor that can be installed on the upper point of the vehi- cle sidewall for a clean and fast installation while providing ease of use. It can be mounted to the existing original equipment shoulder belt location or by using the FE200745 Sidewall Mounting Kit, or into Series L Aluminum Track with the FE200747 Series L Mounting Kit.

FE200936

136" Long

Picture not Available